

Lecteur de badges proximité DGLP - DGLI et DGLI/E


NOTICE DE MONTAGE ET D'UTILISATION

Branchements

Vue de la carte électronique

Avertissement

Ne pas utiliser d'alimentation à découpage à cause de rayonnements parasites pouvant perturber la lecture des badges.



Pour une fixation optimale du produit, veuillez utiliser la visserie fournie. Réaliser alors les perçages à l'entraxe prévu au diamètre de 5mm et sur une profondeur minimale de 35mm


Raccordement du lecteur auxiliaire

Bornier Alimentation

- 12 ----- Alimentation 12V~ ou =
- V ----- Alimentation 12V ~ ou =
- 1 ----- Données
- 4 ----- Commun
- 5 ----- Connection led rouge
- 3 ----- Connection led verte
- 2 ----- Connection buzzer

DGLP - DGLI & DGLI/E Proximity Reader

WIRING DIAGRAM



12	Input voltage 12 V = or ~
V	Input voltage 12 V = or ~
1	Data
4	Common
5	Red LED
3	Green LED
2	Buzzer

FCC statement:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

